




Projecting your PC Laptop

Connect your laptop using the supplied cable. All classrooms with projection support VGA, some classrooms support both VGA and HDMI.



If your laptop only has an HDMI output, you may require an HDMI to VGA adapter. Call x4560 for more info.

Once you connect, your laptop should be mirrored to the screen. If it does not display properly hold down the  key and press the **P** key to cycle through the display options. Typically, in most cases you would select **Duplicate**.



Fix a Distorted Image

If your screen appears distorted try the following steps:

- I. Press the **Auto Image** button on the control panel or touch panel you used to turn on the system. (TV's and Bulfinch classrooms do not have this button.)
2. Adjust your computer's resolution:
 - I. Right-click on the desktop and select **Screen resolution**.
 - II. Click the **Resolution** pull down tab.
 - III. Select the proper resolution for your screen.
 - a. Standard Screen use 1024 x 768
 - b. Widescreen use 1280 x 720

Note: Due to specification changes, many PC laptops are restricted to the Standard screen resolutions when connecting with VGA in older classrooms. This applies to both standard and widescreen projectors.

For Help Call x4560